



Powered by  **GU AUTO TECH** INC.

"Bringing together inspired functionality and industry-leading technology. GU Auto Tech creates leading edge solutions with style and precision. Always striving to give you the best."

www.guautotech.com | contact@guautotech.com

Fax: (213) 377-5166 | Office: 1(800)844-5995

19500 S Rancho Way, Suite 106 Rancho Dominguez, CA 90220

We bring you the GUA 12" Large Touch Screen Wiring instructions manual that showcases our variety of Large screens Wiring instructions.

The following GUA Large Screen Wiring Instructions are shown in this document:

- 1) Ford F-150 Model V1TSM19FE**
- 2) Ford F-150 Model V1TSM19FA**
- 3) Ford F-150 Model V2TSM19FE**
- 4) Ford F-150 Model V2TSM19FA**

The following instructions and technical information are in this instruction document:


- 1) Mainframe lines wiring**
- 2) Mainframe installation instructions (For each GUA Screen Model)**
- 3) Front Cover Assembly lines and wiring**
- 4) Front Cover Assembly installation instructions**

GUA POWERED BY GU AUTO TECH INC. 12" LARGE TOUCH SCREEN


GU Auto Tech inc. proudly brings you the latest GUA 12" Large Touch Screen product for the Ford F-150 trucks. When installing our screen this wiring instruction and diagrams will ensure that your installation is smooth and easy. **Visit our website for the Installations video.**

If you have any questions, please do not hesitate to get in touch with us.

*Please note: All the instructions in this Manual was right and created for the sole purpose to assist buyers of this product to install this to their vehicle. We do not take any responsibility for any harm, damages or loss caused when installing this product. T's & C's Apply.



GPS Antenna




RADIO LINE

Connect to car RADIO



USB LINE


No need to connect the USB plugs of the original car



Knob cable




Other lines Don't Connect



Marked FRONT VIDEO IN Line
Connect to Front Camera (optional)



V2TSM19FE/V2TSM19FA



Connect to CAN



Connect to horn

Connect to POWER


MID-horn line
Don't Connect

Air-conditioner
power connection

MIKE LINE



CVBS Line Connect
to Back Camera




Connect to
Original car plugs



Connect to
Agreement Box

V1TSM19FE/V1TSM19FA



Connect to CAN

Connect to horn




Connect to POWER

MID-horn line
Don't Connect

Air-condition
power connection

Mic LINE

Connect to factory
plugs



Connect to CAN
Agreement Box





12pin to 54pin Converting Line
may be needed for 4.3' Screen
Car; Not necessary for Non -4.3''
Screen Car

Adhesive



Connect to factory A/C cable


GPS Antenna




Connect to factory A/C cable




After the wiring complete, fixed mainframe with two PIN and Lock four screws





Mike connect
Mainframe



Knob line connect Mainframe
with FRONT_COVER_ASM



USB line connect Mainframe
with FRONT_COVER_ASM



Powered by  GU AUTOTECH^{INC.}

"THANK YOU!"